

Original Overhead Door™ Garage Door Paint Formulas

To paint your trim to match your new Steel Overhead Door Garage Door find your color in the chart and use Sherman Williams A100 Exterior Satin Latex.

WHITE a82w151				
A100 GAL.	FULL OZ	1/32 OZ	1/64 OZ	1/128 OZ
B1		2	1	1
G2				1
Y3		1		

DARK BROWN a82t00154				
A100 GAL.	FULL OZ	1/32 OZ	1/64 OZ	1/128 OZ
B1	2	18		1
N1	8	34		
R2		10	1	1

BLACK a82t154				
A100 GAL.	FULL OZ	1/32 OZ	1/64 OZ	1/128 OZ
W1		21	1	1
B1	8	26		1
L1	2	15	1	

Thermacore Brown before 2013

CHESTNUT BROWN a82t154				
A100 GAL.	FULL OZ	1/32 OZ	1/64 OZ	1/128 OZ
W1		4		1
B1		60		1
R3	4	2		
Y3	2	61		

TERRA BRONZE a82w153				
A100 GAL.	FULL OZ	1/32 OZ	1/64 OZ	1/128 OZ
B1	4	22		
N1		22	1	1
R2		12		1
Y3	2	6	1	1

SANDSTONE a82w153				
A100 GAL.	FULL OZ	1/32 OZ	1/64 OZ	1/128 OZ
W1		42		
B1		41	1	1
R2		6		
Y3		37	1	

GRAY a82w151				
A100 GAL.	FULL OZ	1/32 OZ	1/64 OZ	1/128 OZ
B1	4	14		
R2		6		
Y3		36		
R3		12		
L1		3		

Traditional Doors only

TAUPE/391 SAND a82w00153				
A100 GAL.	FULL OZ	1/32 OZ	1/64 OZ	1/128 OZ
W1	2	15	1	
B1		30		
R2		6		
Y3		28		
G2		2	1	

HUNTER GREEN a82t154				
A100 GAL.	FULL OZ	1/32 OZ	1/64 OZ	1/128 OZ
W1		5	1	1
B1	2	32		
L1	4	5	1	
Y3	2	20		1

ALMOND a82w151				
A100 GAL.	FULL OZ	1/32 OZ	1/64 OZ	1/128 OZ
B1		3		
R2		1		
Y3		15		1

DESERT TAN a82w00151				
A100 GAL.	FULL OZ	1/32 OZ	1/64 OZ	1/128 OZ
N1	2	49		1
R3		3		1
Y3		6	1	
G2		1		

color formulas revised 06/21/17

*Mission Oak COMPLEMENTARY A82T00154				
A100 GAL.	FULL OZ	1/32 OZ	1/64 OZ	1/128 OZ
W1		11	1	
B1	4	59	1	1
R2		42	1	1
Y3	4	25	1	
G2		8		

*Golden Oak COMPLEMENTARY A82T00154				
A100 GAL.	FULL OZ	1/32 OZ	1/64 OZ	1/128 OZ
L1		40	1	
R2		31		
R3	2	25		
Y3	4	40	1	1
G2		5		

*Walnut COMPLEMENTARY A82T00154				
A100 GAL.	FULL OZ	1/32 OZ	1/64 OZ	1/128 OZ
W1		29		1
B1	8	20	1	1
R2		17		
Y3		28	1	

*NOTE: COMPLEMENTARY COLORS BLEND WITH BUT DO NOT MATCH STAINED DOOR COLORS

Instructions for re-painting your steel door in it's original factory color.

1. Use a Paint De-Glosser on the door in place of a primer coat (apply the de-glosser to only one section of the door at a time).
2. Apply Top Coast immediatly to this section.
3. Follow label direction and apply as many top coat as necessary for a quality job, make sure to wait the recommended time between coats.

The Genuine. The Original.

